

Fitting Instructions



SKU

PRODUCT

T4Z542

**TAG Heavy Duty Towbar to suit
Hyundai IMAX (02/2008 - on),
iLoad (02/2008 - on)**



Scan for latest
version of these
instructions

SPECIFICATIONS

- Towbar Class: Standard Duty
- Towing Capacity: 1500kg

IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

Towbar Fitting Instructions



Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. Remove 7x plastic scrivit's from under side of bumper and 2x from in wheel arch.
2. Remove 1x screw from wheel arch where top of bumper meets vehicle. 3) Remove tail lights and remove 1x scrivit from under tail light each side.
3. Peel bumper outwards from wheel arch both sides (may require small amount of force) then pull rearward and remove bumper.
4. Undo 2x bolts from under vehicle that are holding the impact beam in place, and discard bolts and impact beam.
5. Offer tow bar to vehicle line up hole's on chassis rails and fit M12 x 130mm bolts to the passenger side and the M12 x 140mm to the driver's side using top plates on opposite side of chassis rails to tow bar, fit spring washers and nuts leaving loose.
6. Fit ½" x 1 3/4" UNC bolts and spring washers through tow bar and shipping hooks into large plates.
7. Tighten all bolts through chassis rails then the ½" bolts.

Towbar Fitting Instructions



8. Cut bumper as follows: (Note: as bumper profiles can change please check Your measurements before cutting to make sure the dimensions are correct).



9. Wire the plug into loom behind driver's side tail light running a wire across to passenger side for left turn signal.

Torque table for bolt tightening

Metric GRADE 8.8
M6 – 9.5 Nm
M8 – 21.7 Nm
M10 – 43.4 Nm
M12 – 77.3 Nm
M16 – 189.8 Nm

Towbar Fitting Instructions



TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au