

FITTING INSTRUCTIONS



PART NUMBER: T2Z505

Hyundai i30 Hatch - 08/06 to 06/11
Towing Capacity 1200 Kg / Ball Load 75 Kg
Lug # L231

- 1) Remove plastic cover from under vehicle.
- 2) Remove exhaust off hangers.
- 3) Do bumper cut. (Note: as bumper profiles can change please check your measurements before cutting to make sure the dimensions are correct).
- 4) Fit tow bar to vehicle with 2 x 10mm bolts and washers into captive nuts on side of chassis rail. 2 x 10mm bolts into captive nuts into bottom of chassis rail.
- 5) Using tow bar as guide drill 2 x 11mm holes into bottom of chassis rail.
- 6) Remove rubber grommet from bottom of chassis rail and fit 2 x 10mm bolts on wire through drilled holes and fit nuts and washers.
- 7) Tighten all bolts to torque listing below.
- 8) Remove plastic ends of guard that was removed in instruction 1. And discard.
- 9) Cut a section out of guard for fitment around tongue plate. 100mm c 20mm approximately.
- 10) Refit exhaust to hangers.
- 11) Refit plastic cover.
- 12) Fit tongue with bolts supplied.
- 13) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8