

## MITSUBISHI PAJERO SPORT QE WAGON 12/15 – ON

PART NO.

**UNT338**

1. On the passenger side locate and open the Jack compartment door.
2. Locate the 10 way connector in the compartment.
3. Secure the earth terminal to a suitable earth point in the compartment.
4. Secure the ECU unit via the adhesive tape to the body of the vehicle.
5. Locate the rear most grommet on the passenger side and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out under the vehicle. This grommet may be in the spare wheel well.
6. Close the Jack compartment door.
7. Open the passenger side front door.
8. Remove the passenger side front door trim and front kick panel
9. Locate the two way connector and the four way connector in the vehicle harness and connect the cabin harness.
10. Replace the passenger side front door trim and front kick panel.
11. Locate the battery power terminal and secure the fuse holder ring terminal to the positive terminal on the battery.
12. Gain access to the four way connector at the rear of the head light.  
Remove the blanking plug and connect the vehicle harness and engine harness.  
Route and secure with cable ties.
13. Returning to the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
14. Using cable ties secure the wiring harness to meet the required length.
15. Fit the required socket to the wiring harness and mount the plug to the desired position.
16. Test towbar wiring with a trailer testing box.

