

TOYOTA PRADO 90 SERIES WAGON 10/97 – 11/01

PART NO.

UNT236

1. Remove trim cover from the passenger side trim panel. Inside the cargo area, remove tool kit and jack.
2. The wiring harness connector is attached to the vehicle harness located within the body cavity.
3. Looking inside the trim panel on the outer wall you will see a grommet.
4. Using a Stanley knife or similar, pierce this grommet in the centre to allow the wiring harness to push through.
5. From the body cavity exposed in the cargo area (step 1) feed the towbar wiring harness down through the grommet.
6. Plug the wiring harness into the vehicle towbar wiring harness connector.
7. Run the white earth wire along the underside of the jack bracket and secure the ring terminal to the jack bracket bolt.
8. Returning to the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
9. Using cable ties secure the wiring harness to meet the required length.
10. Fit the required socket to the wiring harness and mount the plug to the desired position
11. Insert the 15amp mini blade fuse (supplied) into the fuse box located on the passenger side of the engine bay. the correct position for this is the blank slot under "radio no.2". It is recommended that a label (not supplied) be placed on the fuse box cover, in the position mentioned, to show "trailer 15amp".
12. Replace fuse box cover.
13. Test towbar wiring with a trailer testing box.

